
## **Caterpillar EMCP 3.X**




-Customer Connection Cabinet



| Generac Gateway<br>Side Termination | Description | Wire Color   | Customer Side<br>Terminations |
|-------------------------------------|-------------|--------------|-------------------------------|
| TB1 V+                              | DC+         | Red          | BATT +                        |
| TB1 V-                              | DC-         | Black        | BATT -                        |
| TB1 A                               | Data +      | Orange/White | MODBUS +                      |
| TB1 B                               | Data -      | White/Orange | MODBUS -                      |
| TB1 GND                             | Data GND    | White/Blue   | MOD REF                       |
| Harness Relay #1                    | СОМ         | Blue         | BATT -                        |
|                                     | N/O         | White / Blue | DI 2                          |

Expected EMCP 3.X Comm Settings: Baud Rate: 19200 Parity: None Address: 1 If different settings are required, please contact support.

\*If MODEM and signal lights turn off and data is lost after gen crank, this can indicate a brief loss of power. To correct, ensure red and black wires are connected directly to the battery posts.



Generac Power Systems S45 W29290 Hwy. 59, Waukesha WI 53

Generac.com/Industrial 1-888-234-3212 option 4



©2023 Generac Power Systems. All rights reserved. Specifications are subject to change without notice.